STEERING PAD SWITCH

■DESCRIPTION

- Steering pad switches are standard equipment on all models.
- The steering pad switches that are provided on the steering pad may vary due to optional equipment, as indicated in the table below.

System	Switch	Equipment			
		Standard	Navigation	Dynamic Radar Cruise	Navigation & Dynamic Radar Cruise
Audio	● VOLUME +/- ● SEEK +/- ● MODE	○	○	○	○
Multi-information Display (Combination Meter)	DISP	○	○	○	○
Navigation	VOICE	—	○	—	○
Dynamic Radar Cruise Control	Distance Control	—	—	○	○
Telephone	● ON HOOK ● OFF HOOK	—	○	—	○



01YBE130P